





EMC remarks to DISK-...

Important tips on the laying of cables to ensure fault-free operation

This remarks apply for all DISK variants
like absolute encoder, laser and magnetic tape sensor



If you suspect operational failures you have to carry out the following measures:



Generally, the above measures are applicable also to cables from digital tachogenerators to speed controllers.

In case you will not observe the instructions mentioned above, sporadic troublesome failures may occur, like shut-down of the lift mit signal "encoder error", bypassing of a landing or stopping too late, tripping of the speed monitoring devices, zone faults with signal "SHB-fault" etc.



Read also chapter "EMC Regulations" in the systems description of the control SLC4. STRACK will not assume the liability in case of incorrect installation. Service actions to be carried out by our personnel will be charged to your account. We count on your understanding.